

# Part Number/Price

Part#	Description	Price
68030	Ranger 3 simulator	Consult

## **Options/Accessories**

Part#	Description	Price
21116	Cable (4 ft) with banana plugs	Consult

#### Standard Features

- ABS plastic case, weighs less than 1 lb
- · Fixed rotary switch, -0.5 mV/V to 4.5 mV/V in nine steps of 0.5 mV/V per step
- Ideal tool for calibrating the indicator A/D offset and gain setting
- · A/D calibration steps for -0.5 mV/V for offset and 4.5 mV/V for gain
- · Used in testing, troubleshooting and calibrating digital weight indicators
- Binding posts are color coded to ISA S37.8 standard

# **Specifications**

#### Range:

-0.5 mV/V to 4.5 mV/V

#### Impedance:

350 ohm nominal

# Nonlinearity:

Less than 0.02%

### Connectors:

Binding posts suitable for banana plug or 14-gauge wire

## **Temperature Coefficient:**

±5 ppm/ °C

#### **Dimensions:**

(L × W × H) 4.5 × 3.5 × 1.25 in

# Warranty:

One-year limited

# **Transducer Simulator 4**



## Part Number/Price

Part#	Description	Price
22513	Transducer simulator 4	Consult

## Options/Accessories

Part#	Description	Price
21116	Cable (4 ft) with banana plugs	Consult

## **Standard Features**

- · Designed for high accuracy
- · Sealed lid with neoprene O-ring
- Dustproof and crush tested to 500 lb
- Four operational modes include: vernier adjustment, calibrated adjustment, 0.25 mV/V offset and 0.50 mV/V offset
- Ideal for setpoint or batching simulation

# **Specifications**

#### Range:

Choose any fixed setting  $\pm$  0.25 mV or 0.50 mV through a 10-turn wire-wound potentiometer with locking clutch, fixed and variable

## Maximum Voltage:

15 V

## Linearity:

Less than  $\pm$  0.02% full scale

#### Temperature Coefficient:

Absolute 5 ppm/°C; tracking less than 0.5 ppm/°C

# Load Factors:

Simulates one, two, three, four or eight 350 ohm load cells; or two, four, six, eight or 16 700 ohm load cells

#### Offset:

+0.25 mV/V for use with digitally calibrated meters requiring positive dead load for calibration

## Connectors:

Six-way binding posts, suitable for loose wires or banana jacks

#### Warranty:

One-year limited